

# FITTING GUIDE

## ABOVE DOOR BEACON BRACKET



### Parts Supplied with kit

- 2 x beacon brackets
- Bolt kit

### Tools and Equipment Required

- Allen key set
- Marker
- Drill and drill bit to suit the nutserts
- Nutsert tool
- Small level
- Roof and gutter silicone
- Masking tape
- Auto electrician

### Installation Instructions

1. Identify the driver-side and passenger-side beacon brackets.
2. Apply masking tape to the fitting area.
3. Position the bracket above the door and use a level to adjust its position. Using the mounting holes in the bracket as a guide, mark the hole locations.
4. Drill the marked mounting holes. Take care not to drill too deeply and damage the roof.
5. Remove the masking tape and install the nutserts in all mounting-hole locations.
6. Have an auto electrician connect the beacon to the truck wiring harness and install the cable gland in the roof.
7. Apply silicone inside and around each nutsert.
8. With the beacon attached, position the bracket and secure it using the supplied bolts. Fully tighten all bolts, clean off any excess silicone and remove the protective film from the bracket.
9. Repeat the process on the opposite side.

