

FITTING GUIDE

K220 ADBLUE TANK COVER

Parts Supplied with kit

- 1 x AdBlue tank cover

Tools and Equipment Required

- Spanner set
- Socket set

Installation Instructions

1. Raise the cab
2. Remove the step assembly and retain the factory bolts.
3. Position the AdBlue tank cover over the AdBlue tank.
4. Refit the step assembly, then secure the step assembly and tank cover using the factory bolts.
5. Check the alignment and fully tighten all bolts.
6. Remove the protective film from the AdBlue tank cover.

