

FITTING GUIDE

K220 HINGE COVER



Parts Supplied with kit

- 1 x hinge cover panel
- Bolt kit

Tools and Equipment Required

- Socket set
- Allen keys
- Marker
- Loctite
- Auto electrician, if lights are fitted



Installation Instructions

1. Remove all 4 bolts and the black panel located below the grill.
2. Mark and create openings in the factory mesh at the required mounting-hole locations.
3. Position the hinge cover in place of the factory black panel and in front of the mesh. Align it with the factory mounting holes.
4. Apply Loctite to the supplied bolts, then install and tighten them.
5. If lights are fitted, have an auto electrician connect them to the truck wiring harness.
6. Remove the protective film from the hinge cover.

