

FITTING GUIDE

MIRROR ARM MOUNTED BEACON BRACKET



Parts Supplied with kit

- 2 beacon brackets
- Bolt kit

Tools and Equipment Required

- Small socket set
- Spanner set
- Allen key set
- Auto electrician



Installation Instructions

1. Identify the driver-side and passenger-side beacon brackets.
2. If an aerial is mounted to the mirror arm, remove it and retain it for installation on the beacon bracket.
3. Position the correct beacon bracket on the mirror arm. Fit the P-clips over the mirror arm and align the bolts with the mounting holes in the bracket.
4. Adjust the bracket as required, then fully tighten all bolts.
5. If an aerial was removed, refit it to the beacon bracket.
6. Have an auto electrician fit the beacon and connect it to the truck wiring harness.
7. Remove the protective film.
8. Repeat the process on the opposite side.

