

Sample Fitting Guide

This is a sample PDF for testing the Armoury Group fitting guide upload system.

Product: Example Sunvisor

Vehicle: Kenworth K200

Version: Test Document v1.0

Installation Steps

1. Position the component.
2. Align the mounting points.
3. Install all bolts loosely.
4. Tighten all fasteners to the manufacturer's recommended torque.
5. Inspect the installation before use.

This document is intended for testing purposes only.