

FITTING GUIDE

T360 ADBLUE TANK COVER



Parts Supplied with kit

- 1 x AdBlue tank cover
- Upper and lower mounting brackets

Tools and Equipment Required

- Spanner set
- Socket set



Installation Instructions

1. Fit the upper and lower mounting brackets. Ensure the brackets sit level with chassis
2. Position the AdBlue tank cover and bolt it to the mounting brackets. Check the alignment, then fully tighten all bolts.
3. Remove the protective film from the AdBlue tank cover.

