

FITTING GUIDE

T410 ADBLUE TANK COVER



Parts Supplied with kit

- 1 x AdBlue tank cover
- 1 x bracker

Tools and Equipment Required

- Spanner set
- Socket set

Installation Instructions

1. Fit the supplied bracket to the AdBlue tank cover.
2. Remove the factory bolts from the left side of the exhaust cover and loosen the outer strap on the AdBlue tank. Retain the factory bolts for reuse.
3. Slide the AdBlue tank cover over the tank, ensuring the bracket sits underneath the tank strap.
4. Refit and tighten the factory bolts, then retighten the tank strap.
5. Check the alignment and remove the protective film from the AdBlue tank cover.

