

FITTING GUIDE

T410, T360 KICK PANEL



Parts Supplied with kit

- 2x kick panels
- 6x lights
- Bolt kit



Tools and Equipment Required

- Socket set
- Allen key set
- Marker
- Drill and drill bit set
- Auto electrician

Installation Instructions

1. Identify the driver-side and passenger-side kick panels.
2. Position each kick panel on the corresponding factory under-door panel.
Using the holes in the kick panel as a guide, mark all mounting-hole positions.
3. Remove the kick panels and drill the marked holes to the required sizes.
4. Reposition the kick panels and fit the lights using the supplied bolts.
5. Check the alignment and fully tighten all bolts.
6. Have an auto electrician connect the lights to the truck wiring harness.
7. Remove the protective film from both kick panels.

