

FITTING GUIDE

T410, T360, T610 OLD STYLE BUG DEFLECTOR



Parts Supplied with kit

- 1x stainless bug deflector
- 1x bolt kit

Tools and Equipment Required

- Small socket set
- Small spanner set
- Drill and drill bit suitable for M6 bolts
- Marker



Installation Instructions

1. Position the bug deflector in the centre of the bonnet. Using the mounting holes in the bug deflector as a guide, mark the hole positions on the bonnet.
2. Drill the marked mounting holes.
3. Align the holes in the bonnet with the mounting holes in the bug deflector. Insert the bolts from above, ensuring the nylon washers are positioned between the bug deflector and the bonnet.
4. Tighten all bolts.
5. Remove the protective film from the bug deflector.

