

FITTING GUIDE

T610 HINGE COVER



Parts Supplied with kit

- 1 x hinge cover panel

Tools and Equipment Required

- Socket set
- Allen key
- Loctite
- Auto electrician, if lights are fitted



Installation Instructions

1. Remove all four bolts from the bottom of the grill mesh.
2. Slide the hinge cover behind the bottom of the grill mesh and align it with the factory mounting holes.
3. Apply Loctite to the factory bolts, then reinstall and tighten them.
4. If lights are fitted, have an auto electrician connect them to the truck wiring harness.
5. Remove the protective film from the hinge cover.

