

FITTING GUIDE

KICK PANEL T610 SAR WITH SQUARE TANKS



Parts Supplied with kit

- 2x kick panels with double sided tape fitted
- Bolt kit

Tools and Equipment Required

- Socket set
- Spanner set
- Marker
- Drill and drill bit to suit the supplied bolts



Installation Instructions

1. Identify the driver-side and passenger-side kick panels.
2. Position each kick panel on the corresponding factory under-door panel, aligning it with the existing bolt holes and cut-out.
3. Mark the two front mounting-hole positions.
4. Remove the kick panel, drill the marked holes in the factory under-door panel, then remove the backing from the double-sided tape.
5. Reposition the kick panel, ensuring all mounting holes are aligned, then press firmly into place.
6. Install all bolts and tighten.
7. Remove the protective film from both kick panels



FITTING GUIDE

KICK PANEL T610 SAR WITH ROUND TANKS



Parts Supplied with kit

- 2x kick panels with double sided tape fitted
- Bolt kit

Tools and Equipment Required

- Socket set
- Spanner set
- Marker
- Drill and drill bit to suit the supplied bolts
- Angle grinder with cutting blade



Installation Instructions

1. Identify the driver-side and passenger-side kick panels.
2. Remove the step directly below the door and the factory under-door panel, then use an angle grinder to completely remove any protruding step-mounting brackets.
3. Position each kick panel on the corresponding factory under-door panel, align it with the existing bolt holes and cut-out, then mark the two front mounting-hole positions.
4. Remove the kick panel and drill the marked holes in the factory under-door panel.
5. Reinstall the factory under-door panel, remove the backing from the double-sided tape, then reposition the kick panel and press firmly into place.
6. Install all bolts and tighten.
7. Remove the protective film from both kick panels

