

FITTING GUIDE

T909 AIR HORN MOUNTED BEACON BRACKET



Parts Supplied with kit

- 1 x beacon bracket
- Bolt kit

Tools and Equipment Required

- Small socket set
- Spanner set
- Allen key set
- Auto electrician

Installation Instructions

1. Position the bracket between the air horns to confirm the fitment.
2. Have an auto electrician connect the beacon to the truck wiring harness and install the cable gland in the roof.
3. Position the P-clips on the air horns at the required mounting locations, with the smaller P-clips fitted towards the rear.
4. With the beacon attached to the bracket, position the bracket on the air horns and adjust the P-clips until they align with the mounting holes.
5. Align the supplied bolts with the P-clips through the beacon bracket and loosely install.
6. Check the position, then fully tighten all bolts.
7. Remove the protective film from the beacon.

