

FITTING GUIDE

T909 BUG DEFLECTOR

Parts Supplied with kit

- 1x bug deflector
- 1x bolt kit

Tools and Equipment Required

- Small socket set
- Small spanner set
- 2 people recommended for installation

Installation Instructions

1. Tilt the truck bonnet forward.
2. Remove the six bolts from the outer edges of the grill shell, leaving the front bolts secured.
3. Align the holes in the bug deflector with the corresponding holes in the top of the grill shell.
4. Reinstall the factory bolts.
5. Insert each side of the bug deflector between the grill shell and the side panels, aligning the mounting holes with the existing holes.
6. Loosely reinstall the factory side bolts.
7. Tighten the 4 bolts at the top of the grill shell.
8. Adjust each side as required, then tighten the factory side bolts.
9. Remove the protective film from the bug deflector.

