

FITTING GUIDE

T909 HINGE COVER



Parts Supplied with kit

- 1 x hinge cover panel
- Mounting bolts
- Spacers
- Nutserts



Tools and Equipment Required

- Socket set
- Allen keys
- Nutsert gun
- Marker
- Loctite
- Auto electrician, if lights are fitted

Installation Instructions

1. Position the hinge cover over the bonnet hinge, with the top of the cover resting on top of the hinge. Ensure the cover is centred, then mark the mounting hole locations on the bonnet hinge.
2. Drill the marked holes and install the nutserts.
3. Apply Loctite to the mounting bolts.
4. Position the hinge cover and secure it using the supplied bolts and spacers. The spacers must be positioned between the hinge cover and the bonnet hinge.
5. Tighten the mounting bolts.
6. If lights are fitted, have an auto electrician connect them to the truck wiring harness.
7. Remove the protective film from the hinge cover.

