

FITTING GUIDE

T909 KICK PANEL



Parts Supplied with kit

- 2x kick panels with foam tape fitted
- Bolt kit



Tools and Equipment Required

- Socket set
- Spanner set

Installation Instructions

1. Identify the driver-side and passenger-side kick panels.
2. Position each kick panel under the corresponding door, align the mounting holes with the factory holes in the truck and loosely install the supplied bolts.
3. Check the alignment, then fully tighten all bolts.
4. Remove the protective film from both kick panels.

