

FITTING GUIDE

T909, T659, C509 BUNK WINGS

Parts Supplied with kit

- 2x stainless bunk wings
- Bolt kit

Tools and Equipment Required

- Small socket set
- Small spanner set
- Auto electrician (if lights in wings)

Installation Instructions

1. Identify the driver-side and passenger-side bunk wings.
2. Remove the existing rubber wings, if fitted
3. Position the bunk wings and secure them using using the supplied bolt kit and existing mounting holes.
4. Check the alignment, then fully tighten all bolts
5. If the bunk wings include lights, have an auto electrician connect them to the truck wiring harness.
6. Remove the protective film from both bunk wings.

