

FITTING GUIDE

WEST COAST MIRROR PANELS



Parts Supplied with kit

- 2 x West Coast mirror panels
- 4 x rubber-coated P-clips with bolts
- 2 x blanking plates with rubber grommets

Tools and Equipment Required

- Phillips head screwdriver
- Small spanner set
- Allen key set
- Auto electrician



Installation Instructions

1. Remove the existing lights from the back of mirror and disconnect the wiring. Keeps the screws for reuse.
2. Feed the mirror panel wiring through the rubber grommet in the blanking plate.
3. Have an auto electrician connect the wiring
4. Position the blanking plate in place of the existing light and secure it using the existing mounting holes and screws.
5. Loosen the P-clip nuts on the supplied mirror panel and position the panel on the mirror arm. Ensure the longer leg is positioned on the outside of the mirror. See the fitted photo below.
6. Push any excess wiring back inside the mirror, then tighten the P-clip nuts.
7. Check the positioning and adjust as required.
8. Fit the covers to the top and bottom lights.
9. Remove the protective film from both mirror panels.

